



- Battery life : Approx. 10 months.
- Autonomie de pile : Environ 10 mois.
- Vida de pila : Aprox. 10 meses
- Batteriebensdauer: Ca. 10 Monate.
- 電池壽命 : 大約 10 個月

SEIKO


INSTRUCTIONS
用法説明

SEIKO

TIMER / MINUTERIE / TIMER / TEMPORIZADOR / 定时器



STOPWATCH / CHRONOGRAPHE / STOPPUHR / CRONÓMETRO / 计时秒表



RESET / RÉINITIALISATION / ZURÜCKSETZEN / REPOSICIÓN / 重设

