






SEIKO

INSTRUCTIONS INSTRUCCIONES GEBRAUCHSANWEISUNGEN ISTRUZIONI 用法説明 用法说明

Thank you for purchase of our SEIKO clock.
Please read this instruction manual carefully
before use.



[ENGLISH]

TO START THE CALENDAR

- Insert one "AA" battery into the battery holders.
- Check that the (+) and (-) terminals are properly aligned

TO SET THE CALENDAR

1. How to reset

Push a "RESET" button with a tip of ballpoint pen, etc.

2. How to set year

Push a "SET" button, and a display of "YEAR" starts flashing. Push the "UP" or "DOWN" button to set the year.

- No need of adjustment until the year of 2099

3. How to set month and date

Push a "SET" button again, and a display at "MONTH" and "DATE" starts flashing.

Push the "UP" or "DOWN" button to set the month, then push a "SET" button again to select the date digit and Push the "UP" or "DOWN" button to set the date.

4. How to set hour and minute

Push a "SET" button again, and a display of "HOUR:MINUTE" starts flashing.

Push the "UP" or "DOWN" button to set the hour, then push a "SET" button again to select the minute digit and Push the "UP" or "DOWN" button to set the minute.

Press the "SET" button and the second digits will flash.

Reset the second digits to zero by pressing the "UP" or "DOWN" button.

5. How to confirm display


Push a "SET" button when adjustment finishes. The "MONTH", "DATE" and "DAY" will be displayed.

SPECIFICATION

- Accuracy: +/- 30 seconds per month (in the use of temperature between 5°C and 35°C)
- Operation temperature: 0°C ~ 50°C
- Battery life: Approx. 1 year

SEIKO

INSTRUCTIONS INSTRUCCIONES
GEBRAUCHSANWEISUNGEN
ISTRUZIONI 用法説明 用法说明



How to use the clock

1. Insert the AA battery.
 - If there is an insulator or an insulating cap, remove it.
 - The position of the battery holder or the battery may differ depending on the model.
 - Check that the (+) and (-) terminals are properly aligned.
2. Turn the hand setting knob to set the time.

Battery: AA, 1 piece

Battery life: Approximately 1 year

Remarks: Depending on the item, the battery initially supplied may not have a battery life of 1 year.

Notice d'utilisation de la pendule

1. Insertion de la pile AA.
 - Dans le cas d'un isolant ou d'une pastille isolante, il faut enlever cet élément.
 - L'emplacement de la pile peut varier d'un modèle à l'autre.
 - Vérifier que les polarités (+) et (-) sont bien placées.
2. Tourner le bouton de mise à l'heure pour établir l'heure.

Pile: AA, une pièce

Durée de vie: environ 1 an

A noter : Selon le produit, la pile fournie à l'achat du réveil peut avoir une durée de vie de moins d'un an.